


High-Low Boom Rig (P-HLR)

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



3 x Aluminum Tubes
with Safety Caps



Flight Case



2 x Offset Euro Adapters



1 x Euro Adapter



2 x Pins



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Boom Rig Setup

- Select either of the included Offset Euro Adapters and mount it onto the bazooka. Tighten the provided knob securely.
- Insert one of the Aluminum Tubes into the Offset Adapter and tighten the knob firmly to lock it in place.
- Attach a Safety Cap to one end of the tube. On the opposite end, attach the Tube Connector.
- Insert the provided locking pin into the Tube Connector to ensure maximum safety and stability. Connect the next aluminum tube to the previous one using the Tube Connector.
- Attach any compatible Offset Bowl Adapter Bracket (**Not Included**) onto the tube and tighten it securely using the provided knob.



NOTE: You may also attach the threaded Euro adapter to the tube for Euro-base setups. If no additional configuration is required at the top, cover the tube with a safety cap.



NOTE: The modular design allows a wide range of camera positioning options by combining straight or offset Euro adapters with the aluminum tubes. The rig can be mounted quickly and easily on various support systems such as jib arms, dollies, or cranes.

Euro Setup

- Place the Euro adapter on top of the aluminum tubes.
- Insert the pin into the adapter as shown.
- Ensure that the pin is fully inserted into the adapter and securely locked in place.



YOUR PROAIM HIGH-LOW BOOM RIG ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.